

Vista Mfg., Inc. 53345 Columbia Dr Elkhart, IN 46514

Tunable Aurora

- Easy Installation
- Long life span (50,000 hrs)
- Available in two sizes see below
- Operating voltage: 12 Volts
- Color range: 2600 6500 K
- Two powering options: common ground and common power



DIMENSIONS

3" DIAMETER 4" DIAMETER Ø 2.5" MOUNT HOLE SIZE Ø 3.5" MOUNT HOLE SIZE Ø108.9 [4.286] Ø83.9[3.30] Ø67.6 [2.660] VIEWABLE AREA Ø 46.6 [1.83] VIEWABLE AREA WIRE COLOR (FUNCTION): WIRE COLOR (FUNCTION): RED (WW GND) RED (WW GND) BLACK (+) 3.4 [0.13 2.8 [0.11 BLACK (+) WHITE (CW GND) 3.4 [0.13] 2.8 [0.11] WIRE STRIP LENGTH WHITE (CW GND) WIRE STRIP LENGTH RETAIN SLUGS RETAIN SLUGS 50.8±3.2 [2.00±0.13] JACKET STRIP LENGTH 50.8±3.2 2.00±0.13 JACKET STRIP LENGTH 141.6±6.4 [5.57±0.25] -141.6±6.4 [5.57±0.25]



SPECIFICATIONS

3" DIAMETER AURORA LIGHT SPECS

PART NUMBER	BEZEL COLOR	VOLTAGE (VDC)	CURRENT (mA)	WATTAGE (W MAX)	CCT (K)/ WAVELENGTH (nm)	LUMINOUS FLUX (Im)
440968 COMMON POWER	Tunable White	12	90	1.5	2600 - 6500	65 (WARM WHITE) / 60 (COOL WHITE)
440969 COMMON GROUND						

4" DIAMETER AURORA LIGHT SPECS

PART NUMBER	BEZEL COLOR	VOLTAGE (VDC)	CURRENT (mA)	WATTAGE (W MAX)	CCT (K)/ WAVELENGTH (nm)	LUMINOUS FLUX (lm)
440970 COMMON POWER	Tunable White	12	120	2.0	2600 - 6500	95 (WARM WHITE) / 113 (COOL WHITE)
440971 COMMON GROUND						

INSTALLATION INSTRUCTIONS FOR TUNABLE AURORA

PREPARATION

Keep the following in mind:

- Disclaimer: Drill holes at your own risk
- Verify the location for the light to be installed
- Verify that there is enough clearance for the housing of the product to fit into the intended mounting location
- Maximum recommended material thickness of 1/2"

Determine the appropriate hole size based on the overall diameter of the product

- For 3" diameter assemblies, utilize a 2.5" mounting hole
- For 4" diameter assemblies, utilize a 3.5" mounting hole

WIRING: Determine the wiring configuration used on the product

• 2 Wire Version (1 Power / 1 Ground)

FASTENING: The Aurora lights utilize spring clips only for mounting

- 1. Clean the mounting surface before installing the product
- 2. Fold back the retaining, spring clips and insert the product into the mounting hole

Vista reserves the right to modify this specification without prior notice.

Red Wire (Power) Grey Wire (Ground)

P: 574.264.0711 | **F:** 574.264.4174 | vistamfg.com

DISCONNECT POWER SOURCE (BATTERY) BEFORE STARTING ELECTRICAL WORK.

Recommended methods for splicing wires together (parts not included in Vista product kits):

- Solder and cover bare wires with heat shrink or electrical tape.
- Insulation-displacement connector (IDC) / insulation-piercing contact (IPC).
- Twist on wire connector, "wire nut".
- Crimp connector, "Butt splice".

WIRING:

Route wire as necessary for the application. Do not pinch or puncture wires with fasteners. Do not rout wires around sharp edges. A wire loom should be used for protection if wires are to be routed through areas where they may encounter sharp edges, in an application that would experience high amounts of vibration, in areas that may have fasteners protruding into them during later assembly, or other extreme conditions. Standard wiring outputs can be seen below.

WARNING:

- 1. Supply current and wattage must not exceed the rated values on the specification documents.
- 2. Incorrect polarity or improper wiring may cause personal injury and/or damage to the product. It is recommended that an electrical technician, professional, or similarly qualified individual finish wiring.
- 3. To avoid electrical shock risk, all failures should be examined by a qualified technician.
- 4. Environmental suitability, including but not limited to water resistance, varies based on product design. Unless explicitly noted, products are to be installed in a location shielded from outdoor elements. To avoid irreparable damage, refer to specification sheets to locate products in a proper environment.
- 5. Do not install products near an open flame or in high temperature environments unless the product is explicitly designed to function as such. Adversely, do not install products in excessively cold environments unless explicitly designed to function as such. Refer to product spec sheets/drawings for information about minimum and maximum operating temperatures.
- 6. Vista Manufacturing, Inc. is not liable for any injuries or damage caused due to improper wiring or installation.

Vista reserves the right to modify this specification without prior notice.